



Product Information

Leisure Lawns Collection Warranty

Our high-density polyethylene (HDPE) outdoor furniture carries a limited warranty against manufacturer or workmanship defects such as cracking, splitting or breaking for the period of twenty (20) years of residential use or five (5) years of commercial use from the date of original purchase. This warranty will cover replacement parts but does not include labor.

Color Durability

Leisure Lawns poly products have a time-proven record of excellent color durability. Our poly products are manufactured with HDPE featuring UV inhibitors that minimize fading. However, keep in mind that prolonged exposure to the sun will cause all colors to fade to some degree. Orange, red and yellow are most susceptible to fading. Additionally, failing to clean your furniture regularly will void the warranty for poly color issues.

Stainless Steel Fasteners

We use stainless steel fasteners on all of our poly furniture. We use high quality stainless steel to ensure superior protection when exposed to the elements. However, in extreme conditions, such as coastal areas where salt water is present, stainless-steel hardware may require more cleaning and maintenance to avoid corrosion. You should regularly wash or rinse your furniture with fresh water to avoid corrosion. Our hardware fasteners are warranted to not fail structurally for the applicable warranty period (20 years residential use; 5 years commercial use). If not maintained, stainless steel may corrode in certain extreme conditions (coastal areas). If you are in a high acidic area and are concerned about corrosion, we encourage you to add stainless steel paint to your hardware.

Poly Furniture Care

Clean your poly furniture regularly with a non-abrasive soap and water to ensure the continued beauty of your furniture. Colors like white, gray or ivory and other of our lighter colors will need to be cleaned more frequently to maintain their original beauty. With our lighter colors, spray the furniture with a non-abrasive cleaner then wipe the furniture with a cloth and rinse off with warm, clean water. We do not recommend using a pressure washer. But if you choose to use one, do not hold the pressure washer too close to the furniture. It may cause the material to tear away so be sure to hold the top more than 12" away from the furniture.

Do not place items on the furniture that will leave a stain. Do not place hot items directly on the furniture. If properly cared for, you will be able to enjoy your poly furniture for many years!